

TATA Motors iRA Skill for Amazon Alexa

Invocation Name – Tata

Prerequisites –

- *User should have an Amazon Alexa account.*
- *Amazon Alexa app should be installed in user's mobile phone with the Amazon account logged in.*
- *User should have a Voice ID and PIN setup in the Alexa mobile application for the successful execution of the remote commands.*
- *User should be onboarded on Tata Motors iRA mobile application and should have completed the required KYC for using connected vehicle features.*
- *User should have "Tata Motors iRA skill for Amazon Alexa" feature applicable for vehicle and a valid subscription of Tata Motors iRA mobile application.*

Supported Vehicles –

Tata Harrier : Fearless + Matte

Tata Safari : Accomplished + Matte

For Using In-Car Alexa Feature –


For using Tata motors iRA skill for Amazon Alexa inside your car, please sign in to your Amazon shopping app with the same account that you have used to sign into Amazon Alexa app. After successfully signing in, please select the Alexa icon in the infotainment screen of your vehicle and follow the steps displayed on the screen of your car.

Steps to set up Alexa Profile Voice ID-


Step 1: Open the Alexa app, click on the 'More' option.




Step 2: Click on the 'Settings' option.




Step 3: Click on 'Your Profile & Family' option.



Step 4: Then click on the Voice ID option.



Step 5: The Alexa app will guide you through a voice training process. This typically involves recording short phrases spoken by you. Speak clearly in a noise free background for optimal results.



Step 6: Follow the app's instructions carefully and complete the entire training process.


Step 7: After setting up the Voice ID, please follow the steps for the setting up of the Alexa Profile PIN.

Steps to set up/change the Alexa Profile PIN -


Step 1: Open the Alexa app, click on the 'More' option.




Step 2: Click on the 'Settings' option.



Step 3: Click on 'Your Profile & Family' option.



Step 4: Select the 'PIN' option, Enter the phone number to be linked with that Voice ID.




Step 5: Enter the OTP (One Time Password) received on the mobile number entered.

Step 6: After the OTP verification, Enter the new PIN you want to use with the selected Voice ID.


Step 7: Click on the 'Set PIN' button.

Account Linking for Enabling the Tata Motors iRA Skill for Amazon Alexa -


Step 1: To begin the account linking process, open the Tata Motors iRA app and navigate to the 'Profile' tab at the bottom of the screen. From the available options, select "Link iRA Skill for Amazon Alexa" to proceed.



Step 2: This will take you to the Privacy Policy page. Once there, tap the 'Accept & Continue' button to be redirected to the Registration page.



Step 3: The registered mobile number of Tata Motors iRA app will be pre-populated in the Registration screen.



2:35

← Link Alexa

Register

Enter your mobile number to register for an account


Mobile number

+91 9873

Next

Account Linking steps for Loyal and Non-Loyal Customers –

Loyal Customers – If the entered mobile number is associated with a loyal customer, you will be automatically redirected to the already registered page.



2:13


← Link Alexa




You are already registered!

Done

Non-Loyal Customers – If the entered mobile number is associated with a non-loyal customer, you will be prompted to complete the registration process. This includes validating the OTP sent to the provided number to successfully use the Tata Motors iRA skill for Amazon Alexa.




Step 4: Once reached the confirmation page, click on the ‘Open Alexa’ button.




Step 5: Then the Alexa app (if already installed) will open else the user shall be redirected to the Play Store / App Store to install the Amazon Alexa app.

Step 6: Click on the More section of the Alexa app. Then go to Skills & Games. On the top of the page search for the 'Tata Motors iRA' skill in the Search section of the Amazon Alexa app.




Step 7: Click on the LAUNCH / ENABLE TO USE button on the skill's home page.

Step 8: Then enter the registered mobile number and validate the OTP received on the entered mobile number.



Step 8: Then the account will be linked successfully and the Tata Motors iRA skill for Amazon Alexa will be ready to use.



VEHICLE DISCOVERY FOR ADDITIONAL TATA MOTORS VEHICLE

- For the explicit car discovery in case of any changes with the vehicle mapped to the user's account, user must say "Alexa, ask Tata to discover my cars."

Remote Commands

To use **Remote Engine Start** feature-

- Alexa, ask Tata to start/switch on/turn on my car engine.
 - Alexa, ask Tata to start/switch on/turn on my car.
 - Alexa, ask Tata to start my car ignition.
 - Alexa, ask Tata to switch on my car ignition.
 - Alexa, ask Tata to turn on my car ignition.
 - Alexa, ask Tata to start my car for {time} minutes.
 - Alexa, ask Tata to switch on my car for {time} minutes.
 - Alexa, ask Tata to turn on my car for {time} minutes.
 - Alexa, ask Tata to start my car engine for {time} minutes.
 - Alexa, ask Tata to turn on my car engine for {time} minutes.
 - Alexa, ask Tata to switch on my car engine for {time} minutes.
- Possible values for {time}: 2 to 20 minutes

To use **Remote Engine Stop** feature-

- Alexa, ask Tata to stop my car.
- Alexa, ask Tata to switch off my car.
- Alexa, ask Tata to turn off my car.
- Alexa, ask Tata to stop my car ignition.
- Alexa, ask Tata to switch off my car ignition.
- Alexa, ask Tata to turn off my car ignition.
- Alexa, ask Tata to stop my car engine.
- Alexa, ask Tata to turn off my car engine.
- Alexa, ask Tata to switch off my car engine.

To use **Remote Climate Control Start** feature-

- Alexa, ask Tata to start my car air condition/conditioner/conditioning/AC.
- Alexa, ask Tata to turn on my car air condition/conditioner/conditioning/AC.
- Alexa, ask Tata to switch on my car air condition/conditioner/conditioning/AC.
- Alexa, ask Tata to start my car air condition/conditioner/conditioning/AC for {time} minutes and {temp} degree Celsius.
- Alexa, ask Tata to switch on my car air condition/conditioner/conditioning/AC for {time} minutes and {temp} degree Celsius.
- Alexa, ask Tata to turn on my car air condition/conditioner/conditioning/AC for {time} minutes and {temp} degree Celsius.
 - Possible values for {time}: 2 to 20 minutes
 - Possible values for {temp}: 18 to 30 degrees Celsius

To use **Remote Climate Control Stop** feature-

- Alexa, ask Tata to stop my car air condition/conditioner/conditioning/AC.
- Alexa, ask Tata to switch off my car air condition/conditioner/conditioning/AC.
- Alexa, ask Tata to turn off my car air condition/conditioner/conditioning/AC.
- Alexa, ask Tata to stop air condition/conditioner/conditioning/AC of my car.
- Alexa, ask Tata to turn off air condition/conditioner/conditioning/AC of my car.
- Alexa, ask Tata to switch off air condition/conditioner/conditioning/AC of my car.

To use **Remote Hazard Lamp ON** feature-

- Alexa, ask Tata to start my car hazard light.
- Alexa, ask Tata to switch on my car hazard light.
- Alexa, ask Tata to turn on my car hazard light.
- Alexa, ask Tata to start my car hazard lamp.
- Alexa, ask Tata to switch on my car hazard lamp.
- Alexa, ask Tata to turn on my car hazard lamp.

To use **Remote Hazard Lamp OFF** feature-

- Alexa, ask Tata to stop my car hazard light.
- Alexa, ask Tata to switch off my car hazard light.
- Alexa, ask Tata to turn off my car hazard light.
- Alexa, ask Tata to stop my car hazard lamp.
- Alexa, ask Tata to switch off my car hazard lamp.
- Alexa, ask Tata to turn off my car hazard lamp.

To use **Remote Position Lamp ON** feature-

- Alexa, ask Tata to start my car position light.
- Alexa, ask Tata to switch on my car position light.
- Alexa, ask Tata to turn on my car position light.
- Alexa, ask Tata to start my car position lamp.
- Alexa, ask Tata to switch on my car position lamp.
- Alexa, ask Tata to turn on my car position lamp.

To use **Remote Position Lamp OFF** feature-

- Alexa, ask Tata to stop my car position light.
- Alexa, ask Tata to switch off my car position light.
- Alexa, ask Tata to turn off my car position light.
- Alexa, ask Tata to stop my car position lamp.
- Alexa, ask Tata to switch off my car position lamp.
- Alexa, ask Tata to turn off my car position lamp.

To use **Remote Approach Lamp ON** feature-

- Alexa, ask Tata to start my car approach light.
- Alexa, ask Tata to switch on my car approach light.
- Alexa, ask Tata to turn on my car approach light.
- Alexa, ask Tata to start my car approach lamp.
- Alexa, ask Tata to switch on my car approach lamp.
- Alexa, ask Tata to turn on my car approach lamp.
- Alexa, ask Tata to start my car follow me home light.
- Alexa, ask Tata to switch on my car follow me home light.
- Alexa, ask Tata to turn on my car follow me home light.
- Alexa, ask Tata to start my car follow me home lamp.
- Alexa, ask Tata to switch on my car follow me home lamp.
- Alexa, ask Tata to turn on my car follow me home lamp.

To use **Remote Approach Lamp OFF** feature-

- Alexa, ask Tata to stop my car approach light.
- Alexa, ask Tata to switch off my car approach light.
- Alexa, ask Tata to turn off my car approach light.
- Alexa, ask Tata to stop my car approach lamp.
- Alexa, ask Tata to switch off my car approach lamp.
- Alexa, ask Tata to turn off my car approach lamp.
- Alexa, ask Tata to stop my car follow me home light.
- Alexa, ask Tata to switch off my car follow me home light.
- Alexa, ask Tata to turn off my car follow me home light.
- Alexa, ask Tata to stop my car follow me home lamp.
- Alexa, ask Tata to switch off my car follow me home lamp.
- Alexa, ask Tata to turn off my car follow me home lamp.

To use **Remote Door Lock** feature-

- Alexa, ask Tata to lock my car door.
- Alexa, ask Tata to lock my car's doors.
- Alexa, ask Tata to lock my car/vehicle.
- Alexa, ask Tata to secure my vehicle.
- Alexa, ask Tata to activate the lock on my car.
- Alexa, ask Tata to engage the car lock.
- Alexa, ask Tata to please lock my automobile.
- Alexa, ask Tata can you lock my car for me?
- Alexa, ask Tata to initiate the car lock mechanism.
- Alexa, ask Tata to lock the doors of my vehicle.
- Alexa, ask Tata to apply the car lock function.
- Alexa, ask Tata to activate the car security system.
- Alexa, ask Tata to set my car to lock mode.

To use the **Remote Door Unlock** feature-

- Alexa, ask Tata to unlock my car door.
- Alexa, ask Tata to unlock my car's doors.
- Alexa, ask Tata to unlock my car/vehicle.
- Alexa, ask Tata to open the doors of my car.
- Alexa, ask Tata to disengage the lock on my vehicle.
- Alexa, ask Tata to deactivate the car lock.
- Alexa, ask Tata can you unlock my car for me?
- Alexa, ask Tata to release the car lock mechanism.
- Alexa, ask Tata to unlock the doors of my automobile.
- Alexa, ask Tata to turn off the car security system.
- Alexa, ask Tata to remove the car lock function.
- Alexa, ask Tata to disable the car lock feature.
- Alexa, ask Tata to unlock the vehicle.

To use the **Remote Honk** feature-

- Alexa, ask Tata to blow my car horn.
- Alexa, ask Tata to blow my car honk.
- Alexa, ask Tata to trigger my car horn.
- Alexa, ask Tata to trigger my car honk.
- Alexa, ask Tata to honk my car horn.
- Alexa, ask Tata to horn my car honk.

Status Features

To use **Check Distance to Empty** feature –

- Alexa, ask Tata to check my car distance to empty status.
- Alexa, ask Tata to check my car dte status.
- Alexa, ask Tata to read my car distance to empty status.
- Alexa, ask Tata to get my car dte status.
- Alexa, ask Tata how long shall my car run?
- Alexa, ask Tata what is my car distance to empty status?
- Alexa, ask Tata to check my car dte.
- Alexa, ask Tata how many kilometers can my car go?

To use **Car Lock Status** feature-

- Alexa, ask Tata what is my car lock status?
- Alexa, ask Tata to check if my car is locked?
- Alexa, ask Tata to check whether my car is locked?
- Alexa, ask Tata if my car is locked?
- Alexa, ask Tata to check if my car is unlocked?
- Alexa, ask Tata to check whether my car is unlocked?
- Alexa, ask Tata if my car is unlocked?
- Alexa, ask Tata to check my car lock status.
- Alexa, ask Tata if my car is locked or unlocked?
- Alexa, ask Tata to check whether my car is locked or not?
- Alexa, ask Tata is my car locked?
- Alexa, ask Tata can you confirm whether my car is currently locked or not?
- Alexa, ask Tata please check if my car is locked?
- Alexa, ask Tata is the door of my car locked or unlocked right now?
- Alexa, ask Tata can you tell me if my car is currently in a locked state?
- Alexa, ask Tata to check the locking status of my car.
- Alexa, ask Tata is the locking mechanism on my car currently engaged?
- Alexa, ask Tata to please verify whether the doors of my car are locked or not.
- Alexa, ask Tata is the security system of my car activated?
- Alexa, ask Tata can you confirm if my car is currently secured?
- Alexa, ask Tata is the locking mechanism of my car functioning properly?

To use **Check Door Status** feature-

- Alexa, ask Tata what is my car left front door status.
- Alexa, ask Tata to get my car left front door status.
- Alexa, ask Tata if the left front door is locked.
- Alexa, ask Tata if the left front door is unlocked.
- Alexa, ask Tata to check my car left front door status.
- Alexa, ask Tata to get my car front left door status.
- Alexa, ask Tata if the front left door is locked.
- Alexa, ask Tata if the front left door is unlocked.
- Alexa, ask Tata to check my car front left door status.
- Alexa, ask Tata what is my car left rear door status.
- Alexa, ask Tata to get my car left rear door status.
- Alexa, ask Tata to check my car left rear door status.
- Alexa, ask Tata what is my car rear left door status.
- Alexa, ask Tata to get my car rear left door status.

- Alexa, ask Tata to check my car rear left door status.
- Alexa, ask Tata what is my car right rear door status.
- Alexa, ask Tata to get my car right rear door status.
- Alexa, ask Tata to check my car right rear door status.
- Alexa, ask Tata what is my car rear right door status.
- Alexa, ask Tata to get my car rear right door status.
- Alexa, ask Tata to check my car rear right door status.
- Alexa, ask Tata what is my car right front door status.
- Alexa, ask Tata to get my car right front door status.
- Alexa, ask Tata to check my car right front door status.
- Alexa, ask Tata what is my car front right door status.
- Alexa, ask Tata to get my car front right door status.
- Alexa, ask Tata to check my car front right door status.
- Alexa, ask Tata if the driver door is unlocked.
- Alexa, ask Tata to check my car driver door status.

To use the **Odometer reading** feature-

- Alexa, ask Tata to check my car odometer status.
- Alexa, ask Tata to read my car odometer status.
- Alexa, ask Tata to get my car odometer status.
- Alexa, ask Tata what is my car odometer status?
- Alexa, ask Tata to measure the distance travelled by my car.
- Alexa, ask Tata what is the distance travelled by my car?

To use the **Read Temperature status** feature-

- Alexa, ask Tata to check the temperature inside the car.
- Alexa, ask Tata to read my car temperature.
- Alexa, ask Tata what is my car temperature?

To use **the Check Tire Pressure** status feature-

- Alexa, ask Tata to check the pressure of all my tires.
- Alexa, ask Tata to check my car's left front tire pressure.
- Alexa, ask Tata to check my car's left rear tire pressure.
- Alexa, ask Tata to check my car's right front tire pressure.
- Alexa, ask Tata to check my car's right rear tire pressure.
- Alexa, ask Tata to check my car's front left tire pressure.
- Alexa, ask Tata to check my car's rear left tire pressure.
- Alexa, ask Tata to check my car's front right tire pressure.
- Alexa, ask Tata to check my car's rear right tire pressure.

To use the **Fuel level information** status feature-

- Alexa, ask Tata to check my car fuel status.
- Alexa, ask Tata to read my car fuel status.
- Alexa, ask Tata to get my car fuel status.

To use the **Read AC status** feature-

- Alexa, ask Tata to read my car AC status.
- Alexa, ask Tata what is my car AC status?
- Alexa, ask Tata to get my AC status.
- Alexa, ask Tata to check my AC status.
- Alexa, ask Tata is my car AC on?
- Alexa, ask Tata is my car AC off?

To use the **Check Light status** feature-

- Alexa, ask Tata to check my car's light status.
- Alexa, ask Tata to check if my car's lights are on.
- Alexa, ask Tata to check if my car's lights are off.
- Alexa, ask Tata to check my car's hazard light status.
- Alexa, ask Tata to check if my car's hazard lights are on.
- Alexa, ask Tata to check if my car's hazard lights are off.
- Alexa, ask Tata to check my car's position light status.
- Alexa, ask Tata to check if my car's position lights are on.
- Alexa, ask Tata to check if my car's position lights are off.
- Alexa, ask Tata to check my car's approach light status.
- Alexa, ask Tata to check if my car's approach lights are on.
- Alexa, ask Tata to check if my car's approach lights are off.
- Alexa, ask Tata are any lights on in my car?
- Alexa, ask Tata to check if any lights are currently on in my car.
- Alexa, ask Tata to verify if any lights are currently on in my car.
- Alexa, ask Tata if any lights have been left on in my car.
- Alexa, ask Tata if any lights are currently illuminated in my car.
- Alexa, ask Tata to check the current status of the lights in my car.
- Alexa, ask Tata to inform me if any of the lights in my car are currently switched on.
- Alexa, ask Tata if there is any lighting that is currently turned on in my car.
- Alexa, ask Tata to confirm if there are any lights that have been left on in my car.
- Alexa, ask Tata if the lights in my car are turned off at present.
- Alexa, ask Tata if there is any lighting that I need to turn off in my car.

To use the **Power Train** feature-

- Alexa, ask Tata to check the status of engine health.
- Alexa, ask Tata to tell me the health of the engine.
- Alexa, ask Tata to get the status of engine health.

To use the **My Car Information** status feature-

- Alexa, ask Tata to check my car information.
- Alexa, ask Tata to get my car information.
- Alexa, ask Tata to read my car information.
- Alexa, ask Tata to check my car's color.
- Alexa, ask Tata to get my car's color.
- Alexa, ask Tata to check my car's variant.
- Alexa, ask Tata to get my car's make.
- Alexa, ask Tata to check my car's fuel type.

- Alexa, ask Tata to get my car's fuel type.
- Alexa, ask Tata to check my car's registration number.
- Alexa, ask Tata to get my car's registration number.

To use the **Service status** feature-

- Alexa, ask Tata to tell me about my car PUC start date.
- Alexa, ask Tata to tell me about my car PUC end date.
- Alexa, ask Tata to get my car PUC start date.
- Alexa, ask Tata to get my car PUC end date.
- Alexa, ask Tata to tell me about my car PUC details.
- Alexa, ask Tata about my car PUC information.
- Alexa, ask Tata to get my car PUC information.
- Alexa, ask Tata what is my car insurance start date?
- Alexa, ask Tata what is my car insurance end date?
- Alexa, ask Tata to tell me about my car insurance creation date.
- Alexa, ask Tata to tell me about my car insurance last update.
- Alexa, ask Tata what is my car insurance creation date?
- Alexa, ask Tata what is my car insurance last update date?
- Alexa, ask Tata to tell me about my car insurance details.
- Alexa, ask Tata about my car insurance information.
- Alexa, ask Tata to get my car insurance details.
- Alexa, ask Tata when was my car insurance last updated?
- Alexa, ask Tata to get my car insurance information.
- Alexa, ask Tata who is my car insurance provider?
- Alexa, ask Tata what is my car insurance provider's name?
- Alexa, ask Tata when was my car insurance created?
-

To use **Ecosense** feature –

- Alexa, ask Tata to check my driving score for {month} {year}.
 - Alexa, ask Tata to check my car driving score {month} {year}.
 - Alexa, ask Tata to get my driving score for {month} {year}.
 - Alexa, ask Tata what is my driving score for {month} {year}.
 - Alexa, ask Tata to check my car driving score for {ecosense}.
 - Alexa, ask Tata to check my driving score for {ecosense}.
 - Alexa, ask Tata to get my driving score for {ecosense}.
 - Alexa, ask Tata what is my driving score for {ecosense}.
- Possible values for {month}: January, February, March, April, May, June, July, August, September, October, November, December
 - Possible values for {year}: A valid four-digit year
 - Possible values for {ecosense}: Today, yesterday, last week, last month, this week, this month, current week, current month, previous month, this month, previous week

To use **Monthly Health Report** feature-

- Alexa, ask Tata to read my monthly report for {month} {year}.
- Alexa, ask Tata what is my monthly report for {month} {year}?
- Alexa, ask Tata to get my monthly report for {month} {year}.

- Alexa, ask Tata the report for the {month} {year}.
 - Alexa, ask Tata to read my monthly report.
 - Alexa, ask Tata what is my monthly report?
 - Alexa, ask Tata to get my monthly report.
 - Alexa, ask Tata to tell my monthly report.
 - Alexa, ask Tata to check my car monthly report.
-
- Possible values for {month}: January, February, March, April, May, June, July, August, September, October, November, December
 - Possible values for {year}: A valid four-digit year